

# How to use TimestripPlus™

## 1. Inactive



Prior to activation the two windows are white.

## 2. To Activate



Firmly squeeze the bubble on top of the indicator until a blue line appears in the first window. Remove the adhesive liner on the back of the TimestripPlus™ and apply to the product. The product must be stored at below its stop temperature (7°C) within five minutes of activation.

## 3. Activated



As long as the product is held under the threshold temperature, the colour will not progress to the second window.

## 4. Review



Whenever the temperature threshold is breached, the colour moves across the scale, showing the cumulative time it has been above that temperature, allowing the user to take the appropriate remedial action. The colour stops progressing along the run-out window each time the product returns to its stop temperature (7°C).